

```

===== Fixup
PROGRAM FIXUP Fixup
===== Fixup
VERSION 84-1 (NOVEMBER 1984) Fixup
VERSION 86-1 (JANUARY 1986) *IMPROVED BASED ON USER COMMENTS Fixup
*FORTRAN-77/H VERSION Fixup
VERSION 86-2 (JUNE 1986) *ALLOW CREATION OF SECTIONS OF CROSS Fixup
SECTIONS WHICH ARE NOT PRESENT IN Fixup
THE ORIGINAL EVALUATION Fixup
VERSION 88-1 (JULY 1988) *OPTION...INTERNALLY DEFINE ALL I/O Fixup
FILE NAMES (SEE, SUBROUTINE FILEIO Fixup
FOR DETAILS). Fixup
*IMPROVED BASED ON USER COMMENTS. Fixup
VERSION 89-1 (JANUARY 1989) *PSYCHOANALYZED BY PROGRAM FREUD TO Fixup
INSURE PROGRAM WILL NOT DO ANYTHING Fixup
CRAZY. Fixup
*UPDATED TO USE NEW PROGRAM CONVERT Fixup
KEYWORDS. Fixup
*ADDED LIVERMORE CIVIC COMPILER Fixup
CONVENTIONS. Fixup
VERSION 89-2 (MARCH 1989) *ADDED ENDF-6 SUMMATION RULES AND Fixup
DEFINED MF AND MT NUMBERS. PROGRAM Fixup
WILL NOW USE MF=1, MT=451 TO DEFINE Fixup
THE ENDF FORMAT OF THE DATA (E.G., Fixup
ENDF-6 OR EARLIER) AND USE THE Fixup
CORRECT SUMMATION RULES FOR EACH Fixup
VERSION OF THE ENDF FORMAT. IF Fixup
MF=1, MT=451 IS NOT PRESENT PROGRAM Fixup
WILL USE ENDF-6 SUMMATION Fixup
CONVENTIONS AS A DEFAULT. Fixup
VERSION 90-1 (JUNE 1990) *UPDATED BASED ON USER COMMENTS Fixup
*ADDED PHOTON INTERACTION, MF=23 Fixup
VERSION 91-1 (JUNE 1991) *ADDED FORTRAN SAVE OPTION Fixup
*NEW MORE CONSISTENT ENERGY OUTPUT Fixup
ROUTINE Fixup
VERSION 92-1 (JANUARY 1992) *ADDED OPTION TO CALCULATE RATIOS, Fixup
E.G., CAPTURE/FISSION AND PRODUCTS, Fixup
NU-BAR*FISSION - AND OUTPUT THE Fixup
RESULTS IN THE ENDF FORMAT (SEE, Fixup
BELOW - CREATING RATIOS AND PRODUCTS) Fixup
*ALLOW TOTAL NU-BAR (MF=1, MT=452) TO Fixup
BE USED IN DEFINING RATIOS OR Fixup
PRODUCTS. Fixup
*ALLOW ALL CROSS SECTIONS TO BE PUT Fixup
ON A UNIFORM ENERGY GRID. Fixup
*NOTE, CHANGE IN INPUT FORMAT FOR Fixup
RANGES OF MT NUMBERS Fixup
*COMPLETELY CONSISTENT I/O ROUTINES - Fixup
TO MINIMIZE COMPUTER DEPENDENCE. Fixup
VERSION 93-1 (JULY 1993) *CORRECTED ALGORITHM TO CREATE UNIFORM Fixup
ENERGY GRID. Fixup
VERSION 94-1 (JANUARY 1993) *VARIABLE ENDF/B DATA FILENAMES Fixup
TO ALLOW ACCESS TO FILE STRUCTURES Fixup
(WARNING - INPUT PARAMETER FORMAT Fixup
HAS BEEN CHANGED) Fixup
*INCREASED PAGE SIZE FROM 1002 TO Fixup
12000 DATA POINTS. Fixup
*CLOSE ALL FILES BEFORE TERMINATING Fixup
(SEE, SUBROUTINE ENDIT) Fixup
VERSION 96-1 (JANUARY 1996) *COMPLETE RE-WRITE Fixup
*IMPROVED COMPUTER INDEPENDENCE Fixup
*ALL DOUBLE PRECISION Fixup

```

	*ON SCREEN OUTPUT	Fixup
	*UNIFORM TREATMENT OF ENDF I/O	Fixup
	*IMPROVED OUTPUT PRECISION	Fixup
	*DEFINED SCRATCH FILE NAMES	Fixup
	*INCREASED PAGE SIZE FROM 12000 TO 36000 DATA POINTS.	Fixup
VERSION 99-1 (MARCH 1999)	*CORRECTED CHARACTER TO FLOATING POINT READ FOR MORE DIGITS	Fixup
	*UPDATED TEST FOR ENDF FORMAT	Fixup
	VERSION BASED ON RECENT FORMAT CHANGE	Fixup
	*GENERAL IMPROVEMENTS BASED ON USER FEEDBACK	Fixup
VERSION 99-2 (JUNE 1999)	*ASSUME ENDF-6, NOT 5, IF MISSING MF=1, MT-451.	Fixup
	*FIXED CREATION OF SECTIONS	Fixup
VERS. 2000-1 (FEBRUARY 2000)	*GENERAL IMPROVEMENTS BASED ON USER FEEDBACK	Fixup
VERS. 2002-1 (MAY 2002)	*OPTIONAL INPUT PARAMETERS	Fixup
	*SUMMATION RULES ARE DEFINED BASED ON CONTENTS OF TABLES.	Fixup
VERS. 2004-1 (JAN. 2004)	*GENERAL UPDATE BASED ON USER FEEDBACK	Fixup
	*INCREASED PAGE SIZE FROM 36000 TO 60000 DATA POINTS.	Fixup
VERS. 2005-1 (JAN. 2005)	*UPDATED MT CREATION TO ALLOW MAT =0 INDICATING CREATE FOR ALL MATS.	Fixup
VERS. 2007-1 (JAN. 2007)	*CHECKED AGAINST ALL ENDF/B-VII DATA	Fixup
	*INCREASED PAGE SIZE FROM 60,000 TO 600,000 DATA POINTS.	Fixup
VERS. 2007-2 (OCT. 2007)	*ADDED MT=16 AS SUM MT=875 THRU 891 *72 CHARACTER FILE NAMES	Fixup
VERS. 2010-1 (Apr. 2010)	*Defining cross sections by summation to now mandatory - either build-in rules or by user input.	Fixup
VERS. 2011-1 (March 2011)	*Added new MT # to allowed and summation rules.	Fixup
VERS. 2012-1 (Aug. 2012)	*Corrected definition of MT=3 to avoid double counting of MT=18.	Fixup
	*Extended incident particle list to include photon (ZA = 0).	Fixup
	*Added CODENAME	Fixup
	*32 and 64 bit Compatible	Fixup
	*Added ERROR stops.	Fixup
VERS. 2015-1 (Jan. 2015)	*Extended OUT9.	Fixup
	*Replaced ALL 3 way IF Statements	Fixup
VERS. 2015-2 (Oct. 2015)	*Threshold Correction no longer allowed = TOO DANGEROUS!!!	Fixup
VERS. 2017-1 (May 2017)	*Updated based on user feedback	Fixup
	*Increased tables to 3,000,000.	Fixup
	*All floating input parameters changed to character input + IN9 conversion.	Fixup
		Fixup
		Fixup
	OWNED, MAINTAINED AND DISTRIBUTED BY	Fixup
	-----	Fixup
	THE NUCLEAR DATA SECTION	Fixup
	INTERNATIONAL ATOMIC ENERGY AGENCY	Fixup
	P.O. BOX 100	Fixup
	A-1400, VIENNA, AUSTRIA	Fixup
	EUROPE	Fixup
		Fixup
	ORIGINALLY WRITTEN BY	Fixup
	-----	Fixup
	Dermott E. Cullen	Fixup

- HAS A NON-ZERO CROSS SECTION, A POINT WITH ZERO CROSS SECTION IS INSERTED AT THE THRESHOLD. Fixup
- (C) IF THE FIRST TABULATED POINT IS BELOW THE THRESHOLD AND HAS A NON-ZERO CROSS SECTION, ALL POINTS BELOW THE THRESHOLD ARE DELETED AND A POINT WITH ZERO CROSS SECTION IS INSERTED AT THE THRESHOLD. Fixup
- (3) EXTEND ALL CROSS SECTIONS (MF=3) TO 20 MEV. IF THE TABULATED CROSS SECTION ENDS BELOW 20 MEV IT WILL BE EXTENDED TO 20 MEV AS EITHER ZERO (IMOPS(3)=1) OR CONSTANT (IMOPS(3)=2) EQUAL TO THE LAST TABULATED VALUE. Fixup
- (4) ALLOW REACTION (MF=3, ANY MT) DELETION. ALL SPECIFIED REACTIONS WILL BE DELETED WHEN THE DATA IS READ FROM THE INPUT ENDF DATA FILE AND WILL NOT BE IN THE OUTPUT ENDF DATA FILE. WARNING DELETED REACTIONS MAY NOT BE USED TO DEFINE ANY RECONSTRUCTED REACTIONS (I.E. REACTIONS DEFINED BY SUMMING OTHER REACTIONS). SINCE DELETED REACTIONS ARE DELETED DURING READING IT IS AS IF THEY NEVER EXISTED AND IF ANY DELETED REACTION IS REQUIRED LATER TO DEFINE ANY SUM AN ERROR WILL RESULT. THE USER MAY SPECIFY THAT THE DELETION RULES ARE TO BE READ FROM INPUT (IMOPS(4)=1) OR THAT THE BUILT IN SUMMATION RULES ARE TO BE USED (MOPS(4)=2). AT THE PRESENT TIME THE BUILT-IN DELETION RULES ARE THAT NO SECTIONS SHOULD BE DELETED (THE USER MAY OVERRIDE THIS CONVENTION BY INPUT). Fixup
- (5) ALLOW REACTION (MF=3, ANY MT) RECONSTRUCTION BY SUMMING OTHER REACTIONS. IN ORDER TO OPTIMIZE THE RUNNING TIME OF THIS PROGRAM CARE SHOULD BE EXERCISED TO MINIMIZE THE NUMBER OF TIMES THAT EACH CONTRIBUTING CROSS SECTION MUST BE USED. THE USER MAY SPECIFY THAT THE SUMMATION RULES ARE TO BE READ AS INPUT (IMOPS(5)=1) OR THAT THE BUILT IN SUMMATION RULES ARE TO BE USED (IMOPS(5)=2). THE BUILT IN SUMMATION RULES ARE DESIGNED TO USE ENDF CONVENTIONS AND TO MINIMIZE THE NUMBER OF TIMES THAT EACH CROSS SECTION IS USED. Fixup
- (6) INSURE THAT ALL CROSS SECTIONS ARE NON-NEGATIVE (I.E. ARE ZERO OR POSITIVE). DURING READING ALL NEGATIVE CROSS SECTIONS WILL BE SET EQUAL TO ZERO AND TREATED AS SUCH DURING ALL SUBSEQUENT SUMMATIONS AND ENDF OUTPUT. Fixup
- NOTE...THIS OPTION SHOULD NEVER BE USED WITH DATA CONTAINING BACKGROUND CROSS SECTIONS WHICH MAY BE NEGATIVE. ONLY AFTER THE RESONANCE CONTRIBUTION HAS BEEN ADDED TO THE BACKGROUND TO DEFINE THE ACTUAL CROSS SECTION IS IT VALID TO ELIMINATE NEGATIVE CROSS SECTIONS. Fixup
- NOTE...THIS OPTION MAY BE USED TO DELETE NEGATIVE ELASTIC CROSS SECTIONS THAT MAY RESULT FROM RECONSTRUCTING CROSS SECTIONS FROM SINGLE LEVEL BREIT-WIGNER PARAMETERS. IF THE TOTAL CROSS SECTION IS THEN RECONSTRUCTED USING THE CORRECTED ELASTIC CROSS SECTION THE TOTAL WILL BE POSITIVE DUE TO THE CONTRIBUTIONS OF CAPTURE AND FISSION (THUS AVOIDING NUMERICAL INSTABILITY PROBLEMS DURING SELF-SHIELDING CALCULATIONS). Fixup
- (7) WITHIN EACH SECTION OF CROSS SECTIONS DELETE ENERGIES THAT ARE NOT IN ASCENDING ENERGY ORDER (ENERGY REPETITION IS O.K.) Fixup
- (8) WITHIN EACH SECTION OF CROSS SECTIONS ELIMINATE DUPLICATE POINTS (SUCCESSIVE POINTS WITH THE SAME ENERGY-CROSS SECTION). Fixup
- (9) TEST THAT ALL SECTIONS ARE IN ASCENDING MAT/MF/MT ORDER. IF NOT, NO CORRECTIVE ACTION WILL BE TAKEN, ONLY AN ERROR MESSAGE WILL BE OUTPUT. Fixup
- (10) CHECK MF/MT FOR EACH SECTION TO INSURE THAT THEY ARE DEFINED IN THE ENDF FORMAR MANUAL. IF THEY ARE NOT DEFINED AN ERROR MESSAGE IS PRINTED, BUT NO CORRECTIVE ACTION IS TAKEN. Fixup
- (11) ALLOW SECTIONS WHICH ARE NOT PRESENT IN THE ORIGINAL (INPUT) EVALUATION TO BE CREATED. NORMALLY THIS PROGRAM WILL ONLY RECONSTRUCT AND OUTPUT SECTIONS IF THE SECTION IS PRESENT IN THE ORIGINAL EVALUATION. THIS PROCEDURE IS FOLLOWED BECAUSE NORMALLY THE PROGRAM DOES NOT KNOW HOW TO DEFINE THE CONTENTS Fixup

SCRATCH FILE. NEXT, IF THE USER SPECIFIES THAT THEY SHOULD,	Fixup
SECTIONS ARE RECONSTRUCTED. FINALLY ALL CROSS SECTIONS (OLD AND	Fixup
NEW) ARE OUTPUT. WITHIN THE SAME MAT, EACH SECTION AFTER MF=3 IS	Fixup
READ, CHECKED/CORRECTED (BASED ON INPUT OPTIONS) AND OUTPUT.	Fixup
 	Fixup
MF=3	Fixup
=====	Fixup
THE TREATMENT OF THE CROSS SECTIONS REQUIRES UP TO 4 PASSES FOR	Fixup
CROSS SECTIONS. IN THE PROGRAM THEY CORRESPOND TO SUBROUTINES	Fixup
PASS1, PASS2, PASS3 AND PASS4. THE ORIGINAL AND FINAL ENDF DATA	Fixup
FILES, 5 SCRATCH FILES AND 3 IN CORE ARRAYS ARE USED. OPERATIONS	Fixup
PERFORMED DURING EACH PASS ARE,	Fixup
 	Fixup
PASS1	Fixup
=====	Fixup
READ ALL CROSS SECTIONS FROM ITAPE. DELETED ANY SECTIONS. CREATE	Fixup
ANY SECTIONS. CHECK/CORRECT THEM AND WRITE THEM TO SCRATCH FILE.	Fixup
DATA IS READ INTO ARRAY A, TRANSFERRED TO ARRAY C (AFTER EDITING)	Fixup
AND OUTPUT TO ISCRC FROM ARRAY C.	Fixup
ITAPE - UNIT ORIGINAL ENDF DATA IS READ FROM.	Fixup
ISCRC - SCRATCH UNIT THAT EDITED DATA IS WRITTEN ON.	Fixup
TABA - ARRAY INTO WHICH ORIGINAL DATA IS READ.	Fixup
TABC - ARRAY INTO WHICH EDITED DATA IS TRANSFERRED TO AND	Fixup
FROM WHICH IT IS WRITTEN TO ISCRC.	Fixup
 	Fixup
PASS2	Fixup
=====	Fixup
IF A UNIFORM ENERGY GRID IS REQUESTED IT IS CREATED DURING THIS	Fixup
PASS. FIRST ALL OF THE CROSS SECTIONS FROM PASS1 ARE READ AND A	Fixup
UNIFORM ENERGY GRID IS CREATED = ALL ENERGIES THAT ARE INCLUDED	Fixup
IN AT LEAST ONE SECTION (MT) OF CROSS SECTIONS.	Fixup
ISCRA - SCRATCH UNIT CONTAINING UNIFORM ENERGY GRID.	Fixup
ISCRB - SCRATCH UNIT CONTAINING UNIFORM ENERGY GRID.	Fixup
ISCRC - SCRATCH UNIT THAT EDITED DATA IS READ FROM.	Fixup
TABA - ARRAY CONTAINING UNIFORM ENERGY GRID.	Fixup
TABB - ARRAY CONTAINING UNIFORM ENERGY GRID.	Fixup
TABC - ARRAY CONTAINING EDITED DATA.	Fixup
 	Fixup
THE UNIFORM ENERGY GRID ENDS UP ON ISCRB. NEXT EACH SECTION OF	Fixup
CROSS SECTIONS FROM PASS1 IS READ FROM ISCRC, INTERPOLATED TO	Fixup
THE UNIFORM ENERGY GRID AND OUTPUT TO ISCRA. FINALLY ISCRA AND	Fixup
ISCRC ARE SWITCH, SO THAT AT THE END OF THIS PASS THE DATA WILL	Fixup
AGAIN BE ON ISCRC (EXACTLY AS AT THE END OF PASS1), WITH UPDATED	Fixup
POINT COUNTS.	Fixup
ISCRA - SCRATCH UNIT THAT UNIFORM ENERGY GRID DATA IS WRITTEN ON.	Fixup
ISCRB - SCRATCH UNIT CONTAINING UNIFORM ENERGY GRID.	Fixup
ISCRC - SCRATCH UNIT THAT EDITED DATA IS READ FROM.	Fixup
TABA - ARRAY CONTAINING UNIFORM ENERGY GRID DATA.	Fixup
TABB - ARRAY CONTAINING UNIFORM ENERGY GRID.	Fixup
TABC - ARRAY CONTAINING EDITED DATA.	Fixup
 	Fixup
PASS3	Fixup
=====	Fixup
SUMMATION CROSS SECTIONS ARE DEFINED BY READING DATA FROM ISCRC	Fixup
AND MERGING THEM ONTO ISCRA. THE FIRST SECTION THAT CONTRIBUTES	Fixup
TO A SUM IS MERELY COPIED FROM C TO A. IF MORE SECTIONS WILL	Fixup
CONTRIBUTE TO THE SUM THE DATA IN A IS TRANSFERRED TO B, A	Fixup
SECTION OF DATA FROM C IS ADDED TO THE DATA IN B AND STORED IN	Fixup
A. THE CYCLE OF ADDED C AND B TO A, FOLLOWED BY MOVING A TO B	Fixup
IS CONTINUED UNTIL ALL CONTRIBUTING SECTIONS HAVE BEEN ADDED.	Fixup
THE SUM IS THEN COPIED FROM A TO D. IF NEWLY CONSTRUCTED SECTION	Fixup
IS REQUIRED FOR ANY LATER SUMMUATIONS IT IS ALSO COPIED TO E.	Fixup
THE CYCLE OF ADDED SECTIONS FROM C AND B TO A IS REPEATED FOR	Fixup

EACH REQUIRED SUMMATION REACTION. IN ADDITION TO SECTIONS FROM C, AFTER THE FIRST SUMMATION SECTIONS MAY ALSO BE ADDED TO A FROM E (THE CONTRIBUTION OF NEW RECONSTRUCTED CROSS SECTIONS). WHEN ALL REQUIRED SECTIONS HAVE BEEN RECONSTRUCTED THE NEW SECTIONS WILL BE ON E AND THE ORIGINAL SECTIONS ON C.

ISCR - SCRATCH FILE FROM WHICH ORIGINAL DATA IS READ.
 ISCR - SCRATCH FILE ONTO WHICH SUM FOR ONE SECTION IS WRITTEN.
 ISCRD - SCRATCH FILE ONTO WHICH ALL SUM CROSS SECTIONS ARE WRITTEN.
 ISCRE - SCRATCH FILE ONTO WHICH ALL SUM CROSS SECTIONS WHICH ARE REQUIRED FOR LATER SUMS ARE WRITTEN.
 ISCRB - UTILITY SCRATCH FILE USED TO CREATE SUM CROSS SECTIONS.
 TABA - ARRAY INTO WHICH SUMS ARE WRITTEN.
 TABB - ARRAY INTO WHICH PARTIAL SUMS ARE WRITTEN.
 TABC - ARRAY INTO WHICH ORIGINAL DATA IS READ.

PASS4
 =====

CROSS SECTIONS ARE READ FROM ISCR (ORIGINAL) AND ISCRD (NEW) AND ARE WRITTEN IN THE ENDF FORMAT ON OTAPE. THE BEGINNING OF EACH SECTION OF ORIGINAL DATA IS READ FROM ISCR (TO DEFINE SECTION HEADER INFORMATION). IF THIS MT HAS NOT BEEN RECONSTRUCTED ON ISCRD THE ORIGINAL SECTION IS OUTPUT. IF THE SECTION HAS BEEN RECONSTRUCTED THE ORIGINAL SECTION IS SKIPPED AND THE NEW SECTION IS OUTPUT.

OTAPE - OUTPUT DATA IN THE ENDF FORMAT.
 ISCR - SCRATCH FILE FROM WHICH ORIGINAL DATA IS READ.
 ISCRD - SCRATCH FILE FROM WHICH NEW DATA IS READ.
 TABC - ARRAY INTO WHICH CROSS SECTIONS ARE READ FROM SCRATCH AND WRITTEN TO OTAPE

I/O FILE DEFINITIONS
 =====

UNIT	DESCRIPTION
=====	=====
2	INPUT PARAMETERS.
3	OUTPUT REPORT.
10	ORIGINAL DATA IN THE ENDF FORMAT.
11	FINAL DATA IN THE ENDF FORMAT.
12	SCRATCH FILE
14	SCRATCH FILE
15	SCRATCH FILE
16	SCRATCH FILE
17	SCRATCH FILE

OPTIONAL STANDARD FILE NAMES (SEE SUBROUTINE FILIO1 AND FILIO2)
 =====

UNIT	FILE NAME	FORMAT
=====	=====	=====
2	FIXUP.INP	BCD
3	FIXUP.LST	BCD
10	ENDFB.IN	BCD
11	ENDFB.OUT	BCD
12-17	(SCRATCH)	BINARY

INPUT LINES
 =====

LINE	COLUMNS	FORMAT	DESCRIPTION
=====	=====	=====	=====
1	1-14	14I1	INPUT OPTIONS AS DESCRIBED ABOVE. EACH COLUMN OF THE INPUT LINE CONTROLS ONE OF THE TESTS/CORRECTIONS DESCRIBED ABOVE. TESTS/CORRECTION 1-14 (NOT ALL

			IMPLEMENTED YET) CORRESPOND TO COLUMNS	Fixup
			1-14 OF THIS INPUT LINE AND ARE TREATED	Fixup
			AS FOLLOWS,	Fixup
			= 0 - DO NOT PERFORM TEST/CORRECTION.	Fixup
			= 1 - PERFORM TEST/CORRECTION.	Fixup
			FOR MT EXCLUSION FROM THRESHOLD TESTS	Fixup
			(COLUMN 2), DELETION (COLUMN 4), OR	Fixup
			SUMMATION (COLUMN 5) THE INPUT OPTION	Fixup
			MAY BE,	Fixup
			= 1 - READ RULES FROM INPUT	Fixup
			= 2 - USE BUILT-IN RULES	Fixup
2	1-72	A72	ENDF INPUT DATA FILENAME	Fixup
			(STANDARD OPTION = ENDFB.IN)	Fixup
3	1-72	A72	ENDF OUTPUT DATA FILENAME	Fixup
			(STANDARD OPTION = ENDFB.OUT)	Fixup
4-M	1-5	FREE	CHARACTER (S,D,T,R,*) FOLLOWED BY BLANK OR	Fixup
		FORM	MT NUMBER	Fixup
			- THE ALLOWED CHARACTERS ARE,	Fixup
			- S OR BLANK = SUM (OR DIFFERENCES)	Fixup
			- D = DELETE	Fixup
			- T = NO THRESHOLD ENERGY CORRECTIONS	Fixup
			- R = RATIO	Fixup
			- * = PRODUCT	Fixup
6-72		FREE	UP TO 10 LOWER AND UPPER MT RANGES WHICH	Fixup
		FORM	WILL BE USED TO DEFINE THE RECONSTRUCTED	Fixup
			CROSS SECTION OR TO DEFINE MT RANGES WHICH	Fixup
			ARE EXCLUDED FROM THRESHOLD TESTS.	Fixup
				Fixup
			EACH MT NUMBER IS DEFINED BY A CONTINUOUS	Fixup
			STRING OF DIGITS, POSSIBILITY PRECEDED BY	Fixup
			A - (MINUS SIGN). EACH MT NUMBER MUST BE	Fixup
			BLANK OR OTHERWISE (NOT A DIGIT) DELIMITED.	Fixup
				Fixup
			COLUMNS 6-72 MAY CONTAIN STRINGS OF DIGITS	Fixup
			THE FIRST DIGIT STRING OF EACH PAIR MAY BE	Fixup
			PRECEDED BY A - (MINUS SIGN).	Fixup
				Fixup
			EACH LINE WILL BE INTERPRETED AS FOLLOWS,	Fixup
				Fixup
			*SUMMATION (OR DIFFERENCES)	Fixup
			-----	Fixup
			COLUMNS 1-5 = S OR BLANK FOLLOWED BY THE	Fixup
			MT NUMBER TO BE DEFINED BY SUMMATION	Fixup
				Fixup
			COLUMNS 6-72 = UP TO 10 MT RANGE (PAIRS OF	Fixup
			MT NUMBERS) TO BE USED TO DEFINED THE SUM.	Fixup
			IF THE FIRST MT NUMBER OF A PAIR IS	Fixup
			NEGATIVE THE RANGE OF MT NUMBERS IS	Fixup
			SUBTRACTED - AT LEAST ONE RANGE MUST BE	Fixup
			SPECIFIED.	Fixup
				Fixup
			*DELETIONS	Fixup
			-----	Fixup
			COLUMNS 1-5 = D FOLLOWED BY BLANKS	Fixup
				Fixup
			COLUMNS 6-72 CONTAIN UP TO 10 MT RANGE	Fixup
			(PAIRS OF MT NUMBERS), EACH RANGE DEFINING	Fixup
			A RANGE OF MT NUMBERS TO BE DELETED - AT	Fixup
			LEAST ONE RANGE MUST BE SPECIFIED.	Fixup
				Fixup
			*EXCLUSION FROM THRESHOLD TESTS	Fixup
			-----	Fixup
			COLUMNS 1=5 = T FOLLOWED BY BLANKS	Fixup

			COLUMNS 6-72 CONTAIN UP TO 10 MT RANGE	Fixup
			(PAIRS OF MT NUMBERS), EACH RANGE DEFINING	Fixup
			A RANGE OF MT NUMBERS WHOSE THRESHOLD	Fixup
			ENERGY WILL NOT BE CHECKED - AT LEAST ONE	Fixup
			RANGE MUST BE SPECIFIED.	Fixup
			*RATIO	Fixup
			-----	Fixup
			COLUMNS 1-5 = R FOLLOWED BY THE MT NUMBER	Fixup
			TO BE DEFINED BY A RATIO	Fixup
			COLUMNS 6-72 CONTAINS 2 MT NUMBERS TO BE	Fixup
			USED TO DEFINE THE RATIO.	Fixup
			*PRODUCT	Fixup
			-----	Fixup
			COLUMNS 1-5 = * FOLLOWED BY THE MT NUMBER	Fixup
			TO BE DEFINED BY A PRODUCT	Fixup
			COLUMNS 6-72 CONTAINS 2 MT NUMBERS TO BE	Fixup
			USED TO DEFINE THE PRODUCT.	Fixup
			CONVENTIONS	Fixup
			-----	Fixup
			*UP TO 20 DELETIONS AND 20 SUMMATIONS OR	Fixup
			RATIOS OR PRODUCTS MAY BE SPECIFIED.	Fixup
			*ONLY 1 EXCLUSION FROM THRESHOLD TESTS	Fixup
			MAY BE SPECIFIED (THE 1 LINE MAY CONTAIN	Fixup
			UP TO 10 MT RANGES TO EXCLUDE FROM TESTS).	Fixup
			*INPUT IS TERMINATED BY INPUTTING 0 OR	Fixup
			BLANK IN COLUMNS 1-72 (I.E. THE LAST	Fixup
			INPUT LINE MUST BE BLANK).	Fixup
			*THE UPPER LIMIT OF EACH RANGE MUST BE AT	Fixup
			LEAST AS BIG AS THE LOWER LIMIT (IN	Fixup
			ABSOLUTE VALUE).	Fixup
			*FOR RECONSTRUCTION POSITIVE MT RANGES WILL	Fixup
			BE ADDED TO THE SUM AND NEGATIVE MT RANGES	Fixup
			WILL BE SUBTRACTED.	Fixup
			*IF INPUT OPTION 2 (FIRST INPUT LINE) IS	Fixup
			0 THRESHOLD EXCLUSION IS NOT ALLOWED.	Fixup
			*IF INPUT OPTION 4 (FIRST INPUT LINE) IS	Fixup
			0 DELETIONS ARE NOT ALLOWED.	Fixup
			*IF INPUT OPTION 5 (FIRST INPUT LINE) IS	Fixup
			0 SUMMATIONS AND RATIOS ARE NOT ALLOWED.	Fixup
			IF THE USER SPECIFIES THAT SECTIONS WHICH	Fixup
			ARE NOT PRESENT IN THE ORIGINAL EVALUATION	Fixup
			MAY BE CREATED, TWO LINES MUST BE INPUT FOR	Fixup
			EACH SECTION TO BE CREATED. THE TWO LINES	Fixup
			DEFINE (C1, C2, L1 AND L2) FOR EACH OF THE	Fixup
			FIRST TWO LINES OF THE SECTION TO BE	Fixup
			CREATED. THE FIRST LINE ALSO DEFINES (MAT	Fixup
			AND MT). (N1, N2) ARE ALWAYS ZERO ON THE	Fixup
			FIRST LINE AND WILL BE CALCULATED BY THE	Fixup
			PROGRAM FOR THE SECOND LINE.	Fixup
FIRST	1-11	E11.4	ZA OF SECTION TO BE CREATED	Fixup
LINE	12-22	E11.4	AWRE OF SECTION TO BE CREATED	Fixup
	23-33	I11	L1 OF SECTION TO BE CREATED	Fixup
	34-44	I11	L2 OF SECTION TO BE CREATED	Fixup
	45-48	I4	MAT OF SECTION TO BE CREATED	Fixup
	49-51	I3	MT OF SECTION TO BE CREATED	Fixup
SECOND	1-11	E11.4	C1 OF SECTION TO BE CREATED	Fixup
LINE	12-22	E11.4	C2 OF SECTION TO BE CREATED	Fixup

N-K

	23-33	I11	L1 OF SECTION TO BE CREATED	Fixup
	34-44	I11	L2 OF SECTION TO BE CREATED	Fixup
			*PAIRS OF LINES MAY BE IN ANY MAT/MT ORDER	Fixup
			(E.G., THEY NEED NOT BE IN ASCENDING	Fixup
			MAT/MT ORDER).	Fixup
			*UP TO 50 PAIRS OF LINES MAY BE USED TO	Fixup
			DEFINE SECTIONS TO BE CREATED. THE LIST	Fixup
			IS TERMINATED WHEN THE FIRST LINE OF A	Fixup
			PAIR CONTAINS A ZERO (OR BLANK) MAT AND/OR	Fixup
			MT.	Fixup
M-N			IF THE USER SPECIFIES THAT ENERGIES WHICH	Fixup
			ARE NOT PRESENT IN THE ORIGINAL EVALUATION	Fixup
			MAY BE INSERTED, ONE LINE MUST BE INPUT FOR	Fixup
			EACH ENERGY TO BE INSERTED.	Fixup
	1-11	E11.4	ENERGY TO BE INSERTED	Fixup
	12-15	I4	MAT IN WHICH TO INSERT ENERGY = 0 = ALL	Fixup
	16-18	I3	MT IN WHICH TO INSERT ENERGY = 0 = ALL	Fixup
			*UP TO 50 (ENERGY, MAT, MT) LINES MAY BE	Fixup
			USED. THE LIST IS TERMINATED BY A BLANK	Fixup
			LINE.	Fixup
			*INPUT MAY BE IN ANY (ENERGY, MAT, MT)	Fixup
			ORDER.	Fixup
			*ENERGY POINTS CAN ONLY BE INSERTED WITHIN	Fixup
			THE ORIGINAL ENERGY RANGE OF A SECTION -	Fixup
			THIS OPTION CANNOT BE USED TO EXTEND THE	Fixup
			CROSS SECTION EITHER BELOW OR ABOVE THE	Fixup
			ORIGINAL TABULATED ENERGY RANGE.	Fixup

EXAMPLE INPUT NO. 1

=====

	(1)	USE OPTIONS 1-11 (ALL OPTIONS, EXCEPT INSERT ENERGY POINTS)	Fixup
	(2)	DELETE MT=900 (FOR EXAMPLE PURPOSES ONLY)	Fixup
	(3)	DEFINE THE FOLLOWING MT NUMBERS TO BE RECONSTRUCTED,	Fixup
		(MT= 4) = THE SUM OF MT= 51 THROUGH 91	Fixup
		(MT=103) = THE SUM OF MT=700 THROUGH 718 (NOT 719)	Fixup
		(MT=104) = THE SUM OF MT=720 THROUGH 738 (NOT 739)	Fixup
		(MT=105) = THE SUM OF MT=740 THROUGH 758 (NOT 759)	Fixup
		(MT=106) = THE SUM OF MT=760 THROUGH 778 (NOT 779)	Fixup
		(MT=107) = THE SUM OF MT=780 THROUGH 798 (NOT 799)	Fixup
NEW		(MT= 16) = THE SUM OF MT=875 THROUGH 891	Fixup
		(MT=101) = THE SUM OF MT=102 THROUGH 114	Fixup
		(MT= 18) = (MT=19) + (MT=20 AND 21) + (MT=38)	Fixup
		(IF TOTAL FISSION, MT=18, IS NOT PRESENT, DEFINE	Fixup
		IT BY SUMMING FIRST, SECOND, ETC. CHANCE - NOTE	Fixup
		THAT THIS MUST BE DONE IN THIS ORDER, SINCE THE	Fixup
		NEXT SUM INVOLVES USING MT=18.	Fixup
		(MT= 27) = THE SUM OF MT= 18 AND 101	Fixup
		(MT=101 RECONSTRUCTED ABOVE USED IN SUM).	Fixup
		(MT= 3) = THE SUM OF (MT=4)+(MT=6-9)+(MT=16-17)+(MT=22-37)+	Fixup
		(MT=41-45)	Fixup
		(MT=4 AND 27 RECONSTRUCTED ABOVE USED IN SUM).	Fixup
		(MT= 19) = (MT=18) - (MT=20 AND 21) - (MT=38)	Fixup
		(DEFINE FIRST CHANGE FISSION BY SUBTRACTION TO	Fixup
		ALLOW RESONANCE CONTRIBUTION FROM MT=18 TO BE	Fixup
		INCLUDED IN MT=19).	Fixup
		(MT= 1) = THE SUM OF MT=2 AND 3	Fixup
		(MT=3 RECONSTRUCTED ABOVE USED IN SUM).	Fixup
	(4)	THRESHOLD ENERGIES OF THE FOLLOWING MT NUMBERS WILL NOT BE	Fixup
		TESTED OR CORRECTED.	Fixup
		MT=1, 4, 18, 19, 91, 103 THROUGH 114.	Fixup
	(5)	DEFINE MT=254 TO BE THE CAPTURE TO FISSION RATIO (MT=102/18)	Fixup
	(6)	CREATE MAT=1300/MT=254 - NOTE, THIS IS NECESSARY IN ORDER TO	Fixup
		HAVE THE CAPTURE TO FISSION RATIO OUTPUT IN THE ENDF FORMAT	Fixup

